# **HWF2-COM Series**

Honeywell

THE POWER OF CONNECTED

# LTE / IP Single or Dual Path Commercial Fire Communicators

# General

The HWF2-COM Series LTE / IP fire communicators are single or dual path commercial fire alarm communicators that offer contact ID reporting with any fire alarm control panel (FACP) with a built-in dialer.

# Models include:

- HWF2V-COM (Verizon LTE & IP)
- HWF2A-COM (AT&T LTE & IP)

Both models connect directly to the primary or secondary communication ports of a fire panel's digital alarm communicator transmitter (DACT).

Three selectable reporting paths include: LTE cellular only, IP only, or IP primary with LTE cellular backup. All signals from the HWF2-COM Series are delivered to the AlarmNet® network control center which routes highly encrypted cyber secure Ethernet data packets via a customer provided Internet connection or LTE cellular network to the appropriate central station. The AlarmNet® network control center is fully redundant and monitored 24/7.



HWF2V-COM

Easy installation and programming through the AlarmNet 360 website, using the hand-held 7720P Programming tool, or using the control panel's programming mode (for panels that support this option).

# FEATURES & BENEFITS

- LTE and IP connection tested every day
- Three selectable reporting paths: LTE cellular only, IP only, or IP Primary with LTE cellular backup
- Requires no change to the existing FACP configuration
- Connects directly to the primary and secondary telephone ports of a DACT

- Plan choices range from 5 minute, 60 minute, 6 hour, and 24 hour supervision intervals
- Operates over the following communication protocols: LTE, HSPA+(4G) HSPA (3G)
- Works over any type of customer provided
   Ethernet 10/100 based network connection
   (LAN or WAN), DSL
   model or cable modem
- Data transmits over standard contact ID protocol but is secured with the industry's advanced encryption standard (AES 256 bit)
- Supports both dynamic (DHCP) or public and private Static IP addressing
- Reliable connection: IP and cellular connection tested every day
- Built-in, stand alone
   Power Supply module.
   On board charging
   circuit design
   accommodates battery
   back-up. Includes
   primary power and
   battery supervision
- Diagnostic LEDs indicate signal strength and status
- Choice of LTE provider services
- QOS: Quality of Service diagnostics via AlarmNet conveys vital communicator information including signal strength, message path used, and when the message was received
- 7720P Hand-held programmer for easy setup

The HWF2-COM LTE / IP fire communicators operate over the most modern and common cellular networks including LTE, 4G and 3G.

They connect to any customer provided Ethernet 10/100 base network connection (LAN or WAN), DSL or cable modem. Selectable reporting path feature allows the radios to be configured for a single or dual path, while providing appropriate supervision intervals based on NFPA 72 requirements. Selectable paths and supervision timing intervals include:

SELECTABLE PATH	DESCRIPTION	SUPERVISION TIMES
2010 Cell	Single Path, cellular	5 Minutes
2010 IP	Single Path, IP	5 Minutes
2010 IP & Cell	Dual Path IP, cellular	24 Hours
2013 Cell	Single Path, cellular	60 Minutes
2013 IP	Dual Path IP, cellular	60 Minutes
2013 IP & Cell	Dual Path IP, cellular	6 Hours

# Operation

When an event occurs, the FACP goes off hook to dial the central station. The HWF2-COM Series dialer capture module detects the off-hook condition and provides the fire panel with a dial tone. When the fire panel detects the dial tone, it begins dialing the central station.

After the dialing is completed, the dialer capture module returns a signal to the fire panel. The fire panel then sends the contact ID reports to the dialer capture module, which in turn sends a signal after the report is successfully received from the fire panel. The dialer capture nodule sends the contact ID reports to the HWF2-COM Series communications module. When all the reports are sent, the fire panel goes on-hook. The HWF2-COM Series communications module then transmits the messages to the central station either over the LTE network or the Internet (dependent on configuration).

# Fire Communicator / Panel Capability

The HWF2-COM Series is compatible with fire alarm control panels that use the Contact ID communications form as described in the SIA DC-05 standard.

# Easy to Program

The HWF2-COM communicator series can be pre-programmed using the 7720P programmer to enter all central station information. This is saved to the HWF2-COM communicator panel memory. When the HWF2-COM is installed at the site and connected to the Internet/ Intranet, it registers with the AlarmNet Receiver.

For most installations, the only required parameters are:

• Primary City ID (two digits), obtained from your monitoring station

- Primary Central Station ID (two digits), obtained from your monitoring station
- Primary Subscriber ID (four digits), obtained from your monitoring station
- Communication Module MAC ID, and MAC CRC number located on the outside of the box and inside of the module

All parameters are assigned by the monitoring station.

# AlarmNet

AlarmNet communications technology provides a highly reliable alternative for the transmission of alarm signals. The network provides extensive coverage in the United States and Canada. The AlarmNet Network Control Center processes signals from powerful serves in multiple locations equipped with 24/7 infrastructure support. Redundant hardware servers, hot back-up databases and generators with battery back-up at all locations to ensure continuity of service. Signals from AlarmNet are transmitted to central station receivers using multiple communication paths consisting of the Internet, LTE radio network, or toll free plain old telephone service (POTS). Visit AlarmNet.com to learn more.

# Installation Requirements, UL COMPLIANCE

To meet UL864/NFPA, ensure the following;

- HWF2-COM Series must be installed in accordance with the National Fire Protection Association (NFPA) standards 70 and 72
- HWF2-COM Series must be mounted in the same room and within 20 feet of the fire panel.
- HWF2-COM Series and all equipment used for the IP connection (e.g., router, hub, modem, etc) shall be listed and must be powered from an unswitched branch circuit, and be provided with appropriate standby power.
- HWF2-COM Series must use the 7AH battery (not included) to provide 24 hour backup capability

# HWF2-COM Series Technical Specifications

#### ELECTRICAL

#### Transformer:

Primary: 120VAC, 60Hz, 0.5A Secondary: 18VDC, 50VA

#### Battery:

One 12 V 7.0 AH lead-acid battery: (not supplied) Battery charging current: 1 Amp maximum Battery discharge current: Standby 230mA, Active 950mA

#### **CABINET SPECIFICATIONS**

Dimensions: 14.875" H x 12.75" W x 3.0" D (37.8cm H x 32.4cm W x 7.6cm D) Color: Red

### SHIPPING DIMENSIONS:

Weight: 5.3 lbs (6.94kg) Dimensions: 15.625" H x 13.79" W x 9.25" D (39.7cm H x 34.9cm W x 23.9cm D)

#### **TEMPERATURE AND HUMIDITY RANGES**

This system meets NFPA requirements for operation at 0-49°C/32-120°F and at a relative humidity 93%+- 2% RH (non-condensing at 32°C +- 2°C(90°F +-3°F). However the useful life of the system's standby batteries and the electronic components may be adversely affected by extreme temperature ranges and humidity. Therefore, it is recommended that this system and its peripherals be installed in an environment with a normal room temperature of 15 - 27°C/60-80°F.

# **PRODUCT LINE INFORMATION**

HWF2-COM: LTE Digital Cellular Fire Alarm Communicator and Internet Panel Models: HWF2V-COM (Verizon LTE / IP) HWF2A-COM (AT&T LTE / IP) Both models include: Red cabinet with key and lock Wall outlet box Dialer capture module LTE communications module Antenna and mounting adapter

PowerBoost1 power supply

LED display board

Transformer

Manual and required screws Cables, etc.

#### ANTENNA AND EXTERNAL HARDWARE

CELL-ANT3DB: 3dBA gain external/remote antenna WA7626-CA SNA to N Adapter. Works with HWF2-COM Series and IPGSM-4G.

7626-50HC 50 ft. antenna cable, low loss.

**Note:** The CELL-ANT3DB and the WA7626-CA are both required for installing an external antenna along with the 7262-50HC 50 ft antenna cable.

### **OTHER ACCESSORIES:**

**7720P:** HWF2V-COM, HWF2A-COM and IPGSM-4G hand held programmer.

HPTCOVER: Plug-in transformer box for HWF2V-COM, HWF2A-COM and IPGSM-4G communicators. BAT-1270: Battery 12 Volts, 7AH, sealed.

#### AGENCY LISTINGS AND APPROVALS

The listings and approvals below apply to the HWV2V-COM panel. In some cases, certain modules may not be listed by certain approval agencies, or listing may be in process. Consult factory for latest listings.

UL Listed: S789 CSFM: 7300-1545-0199 (pending) FDNY: COA #6219 (pending) ©2019 by Honeywell International Inc. All rights reserved. Unauthorized use of this document is strictly prohibited

This document is not intended to be used for installation purposes. We try to keep our product information up-todate and accurate. We cannot cover all specific applications or anticipate all requirements. All specifications are subject to change without notice.

Country of origin: US

#### Honeywell International, Inc.

12 Clintonville Road Northford, CT 06472 877.HPP.POWR www.honeywellpower.com

DH-62011 | A | 05/19 ©2019 Honeywell International Inc.

